



R1 is only needed if you will be reprogramming the MCU with an SD card in place. If not, you can omit R1 and wire directly from pin 7 to the MCU.

SD card locker

TITLE:	
Document Number:	sdlocker.sch
Date:	REV:
Sheet:	